



Operation:

The AS-110 switch is used to manually turn On/Off the load. If the load is left ON and occupancy is not detected by the sensor, the sensor shuts OFF the power pack, thereby breaking power to the AS-110 switch. If the sensor detects occupancy within 15 seconds from the shut OFF, the load is turned back ON. Otherwise the load remains OFF until the switch is manually turned back ON.

*Configure the AS-110 for occupancy sensor mode operation.

THE WATT STOPPER			
800-879-8585			
Title Occupancy Sensor and AS-110 Automatic Control Switch			
Scale	Drawing#	Date	Rev.
None	Custom	12/5/05	